

XAL-D Pilot Light & Pushbutton



XAL-D112



XAL-D115



XAL-D164



XAL-K174



XAL-K184



XAL-D211



XAL-D213



XAL-D132



XAL-D142



XAL-D363M

Description	Contact Type	Supply voltage	Color	Reference
fiush pushbuttons	N/O	250V 50/60Hz	Green	XAL-D102
				XAL-D103
	N/O+N/C		XAL-D102E	
			N/C	XAL-D112
	N/O+N/C		XAL-D117	
			Red	XAL-D114
	N/C		XAL-D112E	
			XAL-D114E	
			XAL-D115	
			XAL-D118	
fiush pushbuttons	N/O	Green	XAL-D101	
			XAL-D101H29	
N/C	Red	XAL-D111		
		XAL-D111H29		
1 red Mushroom Φ 40mm	N/C			XAL-D164
1 red Mushroom Φ 40mm key pushbutton	N/C			XAL-K174
	N/O+N/C			XAL-K174E
turn to release Φ 40mm	N/O+2N/C			XAL-K178G
1 red Mushroom Φ 40mm key pushbutton	N/C			XAL-K184
	N/O+N/C			XAL-K184E
Key release(keyn ^o 455)red	N/O+2N/C			XAL-K188G
	N/O+N/C			XAL-D211
2 fiush pushbutton	N/O			XAL-D211H29
				XAL-D241
2 fiush pushbutton	N/O+N/C			XAL-D213
				XAL-D224
				XAL-D215
				XAL-D213E
				XAL-D214
1 Rotation pushbutton	N/O			XAL-D225
				XAL-D134
				XAL-D132
				XAL-D144
				XAL-D142
N/O+N/C				XAL-D144E
				XAL-D144
				XAL-D142
				XAL-D144E
2 fiush pushbutton	N/O+N/C			XAL-D363B
				XAL-D363M
1Red lamp	N/O+N/C			XAL-D361B
				XAL-D361M